



#### **ASSEMBLY NOTES:**

1. Install Reflector Screen from the Dipole side of Antenna
2. Using one of the supplied U-Bolt Clamps, fasten the Screen at the top clamp plate to the uppermost point on the Antenna Boom
3. Fasten off remaining Clamps to Antenna Boom

### **Assembly Guide**

## **TV6-RS Rear Reflector Screen** **to** **TV6-Series 4-Stack Array**

**G-Tech** Communication Services Pty. Ltd. Trading as :  
**ZCG SCALAR**®  
 DESIGNERS AND MANUFACTURERS OF RADIO FREQUENCY ANTENNAS  
 Hall Street, Lindenow, Victoria, Australia.  
 Tel: (03) 5157 1203 Fax: (03) 5157 1641



COPYRIGHT - **G-Tech** COMMUNICATION SERVICES PTY.LTD.  
 NO PART OF THIS DRAWING IS TO BE REPRODUCED WITHOUT  
 WRITTEN PERMISSION.