
## Mast or Pole These Nuts can be adjusted for

## **ASSEMBLY:**

- a. Fit an inner 2 sets of Nuts, Spring Washers & Flat Washers to each Allthread
- b. Place a Clamp Bar up to each set of Nuts and Washers
- c. Place around Mast/Pole & fit Clamp Bar, Washers& Nuts then tighten. Fit Locking Nuts tighten
- d. Install Mount Tube following same steps in c.
- e. Install all Locking Nuts tighten

## **Assembly Sketch**

UAM180UNIL-48
CLAMP KIT



Clamp Bar

6

G-Tech Communication Services Pty. Ltd. Trading as:

ZCG SCALAR®

DESIGNERS AND MANUFACTURERS OF RADIO FREQUENCY ANTENNAS

Hall Street, Lindenow, Victoria, Australia.

Tel: (03) 5157 1203 Fax: (03) 5157 1641

Copyright - G-Tech Communication Services Pty. Ltd. No part of this Drawing is to be reproduced without Written Authority

1205-5-B.dwg LM 03-10-13 Approved: GK 03-10-13

Item	Description	Quantity.
1	Clamp Bar, MS, Coated	4
2	Allthread, MS, Galvanised, M12 x 480mm	2
3	Nut, Hex, Galvanised, M12	12
4	Washer, Spring, Galvanised, Ø1/2"	8
5	Washer, Flat, Galvanised, Ø1/2"	8
Ь		

PARTS SUPPLIED:

Locking