

ASSEMBLY NOTES:

- Make sure that the inter-twined Dipoles are reassembled exactly as shown. Matching reassembly Identification Stickers will ensure this.
- Identification Stickers must be matched on Reflectors assembly.
- Mount Antennas with Red Marker Bands above Yagi Boom.
- Apply Amalgamation Tape to Feeder Cable & Phasing Harness Connector joint.

Assembly Sketch

Y206CP CROSS-POLARISED ANTENNA

G-Tech Communication Services Pty. Ltd. Trading as :
ZCG SCALAR[®]
 DESIGNERS AND MANUFACTURERS OF RADIO FREQUENCY ANTENNAS


Hall Street, Lindenow, Victoria, Australia.
 Tel: (03) 5157 1203 Fax: (03) 5157 1641



COPYRIGHT - G-Tech COMMUNICATION SERVICES PTY.LTD.
 NO PART OF THIS DRAWING IS TO BE REPRODUCED WITHOUT
 WRITTEN PERMISSION.

DO NOT SCALE

STEP 1




STEP 2

Second:


Twist to apply to Boom, - bolt in and clip to plastic Saddle after doing Dipole LA1

First:


Twist to apply to Boom, - bolt in and clip to plastic Saddle



STEP 3



STEP 4



Numbered DIRECTORS attached same way as Reflectors.

ASSEMBLY NOTES:

- Make sure that the inter-twined Dipoles are reassembled exactly as shown. Matching re-assembly Identification Stickers will ensure this.

On installation apply Amalgamation Tape over Connector joint

Identification Stickers must be matched on Reflectors assembly.

INSTALLATION NOTES:

- Secure Cables & Phasing Harness with Cable Ties or similar.
- Mount Antennas with Red Marker Bands above Yagi Boom and drain holes below.
- Apply Amalgamation Tape to Feeder Cable & Phasing Harness Connector joint.

Assembly Sketches

Y200CP Series CROSS-POLARISED ANTENNAS